PI-IILIPS VIDECIPAC







Electronic billiards
Billiard
Billiard Americain
Elektronisch biljart
Bigliardo elettronico
Biljard
Billar electronico
Bilhart electronico

PHILIPS



Electronic billiards

This Videopac offers you realistic, electronic versions of two popular American pocket billiard games: "Eight Ball" and "Rotation". Both games are played on a special pocket billiard table.

(For 2 players) Press RESET Next press key 1

Your screen shows the bright red surface of a pocket billiard table. On the left-hand side of the table you see a triangular group of 10 coloured balls. On the right-hand side the white cue ball. The white line moving around the white ball represents the cue.

To select your game

Just move the joystick of either handset when the name of the game you want to play appears on the screen. The player who moves his joystick first starts the game.

If you wait too long making your choice, the computer becomes impatient and starts playing by itselt. As soon as either joystick is moved, however, you can take over. The computer indicates which player is to start (PLAYER L or PLAYER I)....(translate here)...

Playing Eight Ball

In the triangle of ten balls you will see two dark coloured balls. You have to try and get one of those dark balls into a pocket. The tirst player to succeed is the winner.

Determine the direction of your shot by moving the cue with the Joystick of your handset. When you have found the right direction, press the action button. The longer you keep the button depressed, the farther the ball will travel. When your ball hits another one, you no longer control its momentum.

All balls pocketed appear at the bottom of the screen. Keep in mind, however, that only the dark batts count!

Playing Rotation

To play Rotation, move the joystick of either handset when the text "ROTATION" appears. You now have five light blue and tive yellow coloured balls.

Winner is the player who succeeds in pocketing most balls, excluding his own cue ball! There is no difference in value between the blue and the yellow balls.

Players take turns

You may continue to play as long as you succeed in playing a ball into one of the pockets, provided it's not your own cue balt. This applies to both games.

When you tail or when your cue ball lands in a pocket by accident, your turn is over and the other player gets his chance to score.

If the cue ball lands in a pocket, it will immediately reappear on the table in the original cue-off position.

Variations of the Rotation game

The game offers interesting possibilities to create your own variations:

- You may give a different value to the coloured balls.
- You may also decide that lett plays the blue balls only, while the player operating the right handset plays the yellow balls.
- Both players have to try and pocket alternating colours.

You may find yet other variations?

To start a new game, press RESET and key 1, etc.


Check procedure


If you suspect a fault in the equipment follow this procedure (with a Videopac installed). Press RESET (△). The TV will emit a short sound, and 'SELECT GAME' should appear on your TV screen. If not, ensure that the equipment is set up properly as detailed in the Instructions for Use (both of the

equipment, and of the Videopac used). If the fault remains, take both the equipment and Videopac to your dealer.



When selecting 8-Ball or Rotation, never press the action button or any key while you are operating the joystick of your handset!





Move joystick it you want to play 8-Ball

Move joystick if you want to play Rotation



Move toystick to let the computer know which game you want to play. First player To move joystick starts the game.



Player operating left handset starts Start of game Player operating left handsel is to start


by player

handset

operating right



Move joystick to determine direction of your shot



Player operating right handsel has won with a score of 6 to 4

Balls pocketed Balls pockeled by player operating left handset



Operator of right handset has succeeded in pocketing one ol both

dark balls.

Playing 8-Ball

Player operating right handsel has won this game. His opponent has pocketed. Three balls but he has managed to gocket one of the dark coloured balls lirst.

Each time a game is finished, press RESET (A), 'SELECT GAME' is shown on the screen. Now:

(a) Select another game. Or (b) Select another Videopac.

> Remove existing Videopac by placing one hand next to it, and pulling handle upwards.

Replace Videopac In its box.

Refer now to Instructions for Use of the next Videopac.

Or (c) Plug aerial back into TV, and unplug the Videopac Computer from the mains.

Elektronisches Billard

Diese Programm-Cassette bietet realistisch und elektronisch die Version zweier beliebter amerikanischer Pocket-Billardspiele: "Eight Ball" und "Rotation". Beide Spiele werden auf einem speziellen

(Für 2 Spieler) RESET drücken danach Taste 1

Pocket-Billardtisch gespielt.

Ihr Bildschirm zeigt jetzt die hettrote Fläche eines Pocket-Billardtisches. Links auf dem Tisch sehen Sie 10 farbige Kugeln in einem Dreieck angeordnet. Rechts betindet sich die weiße Queue-Kugel. Der weiße Strich, der sich um die weiße Kugel herum bewegt, ist der Billardstock. Spielwahl

Bewegen Sie den Hebel eines der beiden Handregler, wenn das von Ihnen gewünschte Spiel aut dem Bildschirm erscheint. Der Spieler, der seinen Handregler zuerst bedient, beginnt.

Wenn Sie zu lange zögem, wird der Computer ungeduldig und beginnt von sich aus das Spiel. Sobald ein Hebel bewegt wird. können Sie jedoch einsteigen. Der Computer gibt dann an, welcher Spieler beginnen soll (PLAYER L oder PLAYER R = Spieler L oder Spieler R).

Eight Ball

In dem aus 10 Kugeln bestehenden Dreieck erkennen Sie zwei dunklere Kugeln. Sie müssen nun versuchen, eine davon in ein "Pocket" zu bekommen. Der Spieler, dem dies zuerst gelingt, ist der Sieger. Bestimmen Sie die Richtung Ihres Schusses, indem Sie den Billardstock mit dem Hebel Ihres Handreglers bewegen. Wenn Sie die richtige Richtung getunden haben, drücken Sie die Aktionstaste. Je länger Sie diese Taste drücken, de sto weiter rollt die Kugel, Wenn Ihre Kugel eine andere trifft, können Sie ihre Bewegung nicht mehr kontrollieren. Alle Kugeln, die in einen "Beutel" fallen, erscheinen unten auf dem Bildschirm, Denken Sie iedoch daran, daß nur die dunklen Kugeln zählen!

Rotation

Handregler, wenn der Text
"ROTATIQN" erscheint. Sie haben
jetzt fünf heilblaue und fünt gelbe
Kugeln.
Sieger ist der Spieler, der abgesehen von seiner eigenen
Queue-Kugel - die meisten Kugeln
in den Beutel bekommt. Zwischen

Für diese Spiel-Verslon bewegen

Sie den Hebel eines der beiden

Bei Spielende drücke RESET, es verfahrt Gebrau dem Bildschirm. Sie können nun a) ein anderes Spiel aus der c) Steck

den blauen und den gelben Kugeln

b) eine andere Videopac-Cassette nehmen, indem Sie die gerade benutzte an ihrem Handgritt herausziehen. Stecken Sie die Cassette in ihre Schachtel und

Cassette wählen.

Die Spieler wechseln sich ab

Sie können so lange weiterspielen, wie es Ihnen gelingt, Kugeln in eins der Pockets zu bekommen vorausgesetzt, daß es sich nicht um Ihre eigene Queue-Kugel handelt. Dies gilt für beide Spiel-Versionen. Wenn Sie keinen Tretter erzielen oder wenn Ihre Queue-Kugel aus Versehen in einem Beutel landet, erhält der andere Spieler die Chance, Punkte zu erzielen. Wenn die Queue-Kugel in einem Pocket landet, erscheint sie in ihrer ursprünglichen Ausgangsposition sotort wieder auf dem Billardtisch. Variationen zum Rotation-Billard Das Spiel bietet interessante Variations-Möglichkeiten:


- Sie k\u00f6nnen den farbigen Kugeln unterschiedliche Werte zuordnen;
- Sie können sich dafür entscheiden, daß der linke Spieler nur die blauen Kugeln spielt und der rechte Spieler die gelben;
- Beide Spieler müssen
- versuchen, die tarbigen Kugetn


 abwechselnd in die Beutel zu
- abwechselnd in die Beutel zu bekommen.


Vielleicht finden Sie aber noch andere Variationen. Zum Beginn eines neues Spiels RESET drücken und danach Taste † u.s.w.

verfahren Sie nach der Gebrauchsanleitung tür die neue Cassette. c) Stecken Sie die Antenne wieder in das Fernsehgerät und ziehen Sie das Netzteil aus der

Steckdose.








Hebel belätigen, wenn Sie "Eight-Ball" spielen wollen
Beutel

splelen wollen

Drücken Sie die Aktionstaste, um Ihre




Betëtigen Sie Ihren Handregler, damil der Computer weiß, welches Spiet Sie spielen wollen. Der Spieler, der den Handregler zuerst bedient, beginnt




linker Spieler beginnt Spielbeginn: Der Spieler mit dem Inken Handregler beginnt



bestimmen Sie mit dem Hebel ihres Handregiers die Schußrichlung



Rotation: Der Spieler mit dem rechlen Handregler hat 6 : 4 gewonnen



8-Ball: Der Spieler mil dem rechten Handregler hal dieses Spiel gewonnen. Sein Gegner hal 3 Kugeln im Pocket; er dagegen hal eine der dunklen Kugeln als erster im Pocket gehabl

Prüfprogramm

Vermuten Sie einen Fehler, so verfahren Sie mit einer eingesteckten Videopac-Cassette wie tolgt:

Drücken Sie RESET und das Fernsehgerät gibt einen kurzen Ton ab und es sollte 'SELECT GAME' auf dem Bildschirm erscheinen. Ist dies nicht der Fall, überprüfen Sie den Geräteanschluß nochmal wie in der Gebrauchsanleitung angegeben. Funktioniert es trotzdem nicht, so bringen Sie bitte grundgerät und Cassette zu Ibrem Händler.

Die Tasten

RESET: Rückstellen

Die Anweisungen

SELECT GAME: Spielewahl

A copyright protection is claimed on the program stored within the cartridge.

© 1981 N.V. Philips' Gloeilampenfabrieken

3111 106 64610